

# CATTLEMAN INSTALLATION SHEET

**2013 DODGE 1500 2 PCS BUMPER WITH TOW HOOKS**

**#1206**

**6 - 1/2 X 2 1/2 G-8 BLT**

**4 - 1/2 X 2**

**6 - 1/2 NUT G-8**

**4 - 1/2 X 1 1/2**

**12- 1/2 FLAT WASHER G-8**

**8 - 1/2 NUTS**

**6 - 1/2 LOCK WASHER G-8**

**16- 1/2 FLAT WASHER**

**8 - 1/2 LOCK WASHER**

- Step 1 Remove tow hooks and remove tow hook L brackets, replace them with a new L bracket under the P and D bracket and also to the back support bolt as shown use same factory bolts.
- Step 2 Put P brackets and D brackets under the tow hooks then place bottom support bracket under the P and D bracket and also to the back support bolt as shown use the same factory bolts.
- Step 3 Put top bracket under the plastic in the front of the factory bumper, there are two factory holes on the center of the metal bumper 17 1/2 apart bolt on with 2-1/2 x 1 1/2 bolts and to the grille guard tabs.
- Step 4 Place Grille Guard to the P and D bracket.  
Brackets should mount on the inside of the uprights.
- Step 5 Check alignment and tighten bolts.  
You may need to periodically retighten the bolts.

**[www.cattlemanhd.com](http://www.cattlemanhd.com)**

