

CATTLEMAN INSTALLATION SHEET

2009 DODGE 1500 WRAP WITH NO TOW HOOK

Part # 1208

8- 1/2 X 1 1/2" BOLT	6- 1/2 X 2" G8
8 1/2" NUT	6- 1/2" NUT G8
10- 1/2" LOCK WASHER	6- 1/2" LOCK WASHER G8
16- 1/2" FLAT WASHER	12 1/2" FLAT WASHER G8
2- 1.5X12MX40	

- Step 1: Cut an opening on the plastic where the tow hook should be. Then remove the factory bumper nuts and place the "L" bracket as shown and bolt on.
- Step 2: Put the "P" and "D" brackets under the "L" bracket. Put the support bracket under the "P" and "D" brackets and bolt on to the back frame support as shown:
- Step 3: Place top bracket under the plastic and bolt onto the metal bumper and also bolt bracket to the top of the "P" and "D" brackets as shown:
- Step 4: Place grille guard to the "P" and "D" bracket.
Brackets should mount on the inside of the upright
- Step 5: Check alignment and tighten bolts, you may need to periodically retighten the bolts

