

CATTLEMAN INSTALLATION SHEET

09-11 DODGE 1500 WRAP WITH TOW HOOKS

PART # 1209

INSTALLATION WRAP:

8- 1/2X2" BOLT

8- 1/2" NUT

8- 1/2" LOCK WASHER

14- 1/2" FLAT WASHER

2- 1/2X2 1/2" BOLT G8

4- 1/2X 2 1/2" BOLT G8

6- 1/2" NUT G8

6- 1/2" LOCK WASHER G8

12- 1/2" FLAT WASHER G8

- Step 1: Remove tow hook's factory bolts and replace them with 2- 1/2X2 1/2" G8, on the back of the tow hook arm remove factory bolt and reuse bolt.
- Step 2: Place the "P" and "D" brackets under tow hooks, then place bottom support bracket under the "P" and "D" bracket and also to the back support as shown:
- Step 3: Place top bracket under the plastic and bolt on the metal bumper and also bolt bracket to the top of the "P" and "D" brackets as shown:
- Step 4: Place grille guard to the "P" and "D" brackets
Brackets should be mounted on the inside of the upright
- Step 5: Check alignment and tighten bolts
You may need to periodically retighten the bolts

