

CATTLEMAN INSTALLATION SHEET

09-11 FORD F150

PART # 1309

INSTALLATION KIT

8- 1/2x1 1/2" BOLT	12- 1/2" LOCK WASHER
4- 1/2x2" BOLT	22 1/2" FLAT WASHER
12- 1/2" NUT	2- 3/16x2x2" SQUARE WASHER

Step 1: Place bottom bracket under the tow hook as shown:



Step 2: If truck does not have tow hooks, you need to cut an opening for the bottom brackets, and on the bottom of the frame there should be tow holes. Put 2 bolts and bolt on the bottom bracket as shown:

Step 3: Place "L" bracket in the 2 factory front bumper holes and bolt "L" bracket to the bumper bracket holes as shown:

Step 4: Put grille guard in place, bottom bracket should be on the inside of the upright and the top bracket should be on the bottom of the tab as shown:

Step 5: Bolt grille guard on to the brackets and check alignment, then tighten bolts

Step 6: You may need to periodically re-tighten the bolts



www.cattlemanhd.com

