

CATTLEMAN INSTALLATION SHEET

03-05 FORD EXPEDITION

PART # 1318

INSTALLATION KIT

2- 1/2x4 1/2" BOLT
4- 1/2x1 1/2" BOLT
6- 1/2" NUT
6- 1/2" LOCK WASHER
12- 1/2" FLAT WASHER

Step 1: Remove tow hooks one grille guard is in place you can put tow hooks back on

Step 2: Place brackets inside front bumper. Bolt bracket to box frame and to bumper bolt as shown:

Step 3: Once grille guard is bolted onto bottom bracket bolt, strap to grille guard and to the inside bracket as shown.

