

CATTLEMAN INSTALLATION SHEET

2007 GMC 1/2 TON. WRAP

PART # 1417

1- 1/2" X 5" BOLT
12- 1/2 X 2 BOLTS
2- 1/2 X 1 1/2 BOLTS

15- 1/2 NUTS
15- 1/2 LOCK WASHER
30- 1/2 FLAT WASHER

STEP 1: REMOVE TOP GRILL PLASTIC COVER

STEP 2: ON TOP OF THE FRAME REMOVE FACTORY BOLT. PLACE THE INSIDE BRACKET ON THE TOP OF THE FRAME BOTH BRACKETS ARE FACING IN AS SHOWN: BOLT ONE WITH SAME FACTORY BOLTS.

STEP 3: REMOVE FACTORY TOW HOOK BOLTS, PLACE PASSANGER BRACKET ON THE OUTSIDE OF THE FRAME AS SHON. (YOU MAY NEED TO CUT THE PLASTIC ON THE SIDE OF THE TOW HOOK TO CLEAR BOTTOM BRACKET.)

STEP 4: REMOVE FACTORY TO HOOK BOLTS. PLACE OFFSET BRACKET ON THE DRIVER SIDE ON THE INSIDE OF THE FRAME AS SHOW.

STEP 5: PUT GRILL GUARD IN PLACE, CHECL ALIGNMENT ON THE GRILLE GUARD AND TIGHTEN BOLTS.

STEP 6: YOU MAY NEED TO PERIODICALLY TIGHTEN BOLTS!

