

# CATTLEMAN INSTALLATION SHEET

2011 GMC 3/4 TON. HD WRAP

PART # 1419

8- 1/2" X 2 BOLTS  
8- 1/2 NUTS  
8- 1/2 LOCK WASHER  
16- 1/2 FLAT WASHER

- STEP #1 Remove 2 factory side nut close to the front of the frame
- STEP #2 On the driver side you may have to take the factory bolt bracket and put it inside out so you will be able to bolt it on the outside of the frame as shown :
- STEP #3 Place bottom bracket on the outside of the frame and through the tow hook opening and bolt on with the factory bolt,nuts as shown :
- STEP #4 Remove inside factory bumper bolt that is on top of the frame. Place zee bracket facing in and bolt on with the same factory bolt as shown:
- STEP #5 Place top flat bracket to the inside zee bracket as shown:
- STEP #6 Put grill guard in place, bolt on the bottom bracket and then on the top zee bracket as shown:
- STEP #7 Check alignment on the grill guard and tighten bolts.
- STEP #8 You may need to periodically retighten the bolts.

