



### 2007-2013 CHEVY 1500 REPLACEMENT FRONT BUMPER

Part # **2165**

#### Bolts

	Use same factory bolt
Lic.plate	2.- 1/4 x 3/4
	2.- Nuts
	2.- lock washer
	2.- flat washer

**STEP # 1** Remove factory bumper,tow hooks and front end frame brackets.

**STEP # 2** Put replacement bumper in place.Horns should be on the outside of the frame.  
Bolt on with the same factory bolts.

**STEP # 3** Once replacement bumper is in place.Put tow hooks back on.

**STEP # 4** Check alignment on the replacement bumper and tighten bolts

**STEP # 5** You may need to periodically retighten the bolts

