



**2019 - 20 DODGE 2500**

**2265P**

4 - 5/8 X 4 1/2 G8 Bolts  
4 - 5/8 G8 Nuts  
4 - 5/8 G8 Lock Washers  
4 - 5/8 G8 Flat Washers

10 - 1/4 X 3/4 Bolts  
10 - 1/4 Nuts  
10 - 1/4 Lock Nuts  
10 - 1/4 Flat Washers

**NOTE: IF CAMERA IS PRESENT REMOVE THE CENTER HALF PANEL.**

**STEP 1** - Disconnect light and sensor plug if any.

**STEP 2** - Remove tow hooks.

**STEP 3** - Remove factory bumper.

**STEP 4** - Remove lights and sensors from factory bumper if any and place them on the replacement bumper. *NOTE: Remove lights from housing and put them on the replacement light bracket.*

**STEP 5** - Put replacement bumper in place and put tow hook back in place. Bolt the replacement with 4 - factory bolts and 4 - 5/8 x 4 1/2 G8 Bolts.

**STEP 6** - Check alignment on the replacement and tighten bolts.

**STEP 7** - You may need to periodically retighten bolts

